

Operating manual for the Anliker vegetable slicer

Instruction videos can be found on our youtube channel www.youtube.com/@brunneranlikercom


1. Open machine



Preparing the GSM 5 vegetable slicer:

In order to insert a cutting disc, open the latch first and tilt the cutting head to the left.

2. Insert ejector plate



Insert the ejector plate:

Before inserting a disc, the ejection plate must be mounted. If inserted correctly, this almost touches the base of the cutting compartment.

3. Insert disc



Insert the cutting disc:

Now place the disc onto the drive shaft. A short rotation will engage the disc in the drive pin at the drive shaft, seating the top of the disc correctly, i.e. "flush with the drive shaft".

4. Close machine



Close the hopper head:

Tilt the cutting head back into position, insert the vegetable and close the food pusher. Press the vegetables lightly with the pusher. Close the latch for vegetable cutting.

Cleaning manual for the Anliker vegetable slicer

Instruction videos can be found on our youtube channel www.youtube.com/@brunneranlikercom

1. Remove pusher



Removing the pusher:

Tilt the pusher to the left and slide it upwards to remove it.

2. Remove head



Remove cutting head:

The cutting head can be removed completely for cleaning purposes.

After removing the pusher, you can lift up the head.

3. Clean accessories



Cleaning the GSM 5 accessories:

Cutting head, pusher, disc and ejector plate can be cleaned in the dishwasher.

4. Clean machine



Cleaning the GSM 5 basic machine:

The whole basic machine can be cleaned with a damp cloth.